

Model 92JW

Installation Instructions

ASSEMBLY:

- Step 1.** Place frame in upright position, fold down the bed of the frame into an "L" position. With the main assembly in place, align the handle bar to the top of the frame, slide the bar into the designated support holes and secure handle bar to frame with nuts and bolts.
- Step 2.** Apply support rails to each side of frame. Secure rails to frame with nuts and bolts.
- Step 3** Apply the Wheels to the frame. The wheels will go onto the support axle located on the lower rear of the frame behind the bed. Apply the wheels to the axle using the washer on the exterior of the shaft followed by the cotter pin to latch into place.
- Step 4.** Make sure to secure all nuts and bolts to ensure proper working order.

PART NUMBER	HARDWARE	QUANTITY
1	Frame	x1
2	Side Rail	x2
3	1 9/16" L Bolt	x4
4	1 3/8" L Bolt	x2
5	Nut	x6
6	Wheel	x2
7	Handle	x1
8	Washer	x2
9	Cotter Pin	x2

