

Model 801JJ

Installation Instructions

LOWER ASSEMBLY:

First assemble the shovel, strengthening beam and wheel frame to the main frame as shown in the picture, and insert the bolts and nuts in. Second, put the axle through the wheel frame and knock the roll pin's in. Then put the wheels on and insert the cotter pin with its rear open. Last, after adjustment, tighten up the screws.

UPPER ASSEMBLY:

Insert handle #13 to main frame and insert the screws right into the holes. Attach component #12 and tighten up the nuts. Then the assembly of the whole cart is finished.

| PART NUMBER | HARDWARE | QUANTITY |
|-------------|--------------------|----------|
| 1 | Cotter Pin | x 2 |
| 2 | Wheel | x 2 |
| 3 | Washer | x 4 |
| 4 | Bolt | x 8 |
| 5 | Wheel Frame | x 2 |
| 6 | Strengthening Beam | x 2 |
| 7 | Main Frame | x 1 |
| 8 | Shovel | x 1 |
| 9 | Nut | x 8 |
| 10 | Axle | x 1 |
| 11 | Roll Pin | x 2 |
| 12 | Component | x 2 |
| 13 | Handle | x 1 |

