

# Model: 927T

## Installation Instructions

### ASSEMBLY:

**Step 1.** Connect wheels to frame, insert bolts and secure with washers the nuts (see diagram).

**Step 2.** Slide rail through the square openings located at the center of the frame.

**Step 3.** Attach extension arm to rail. Once the extension arm is placed in desired location insert nylon spacer. With nylon spacer in place, insert phillips head bolt through the pre-drilled holes of both nylon spacer and extension arm. Apply washer and nut to secure and stabilize extension arm to rail. Repeat step for all extension arms.

**Step 4.** Finished

PART NUMBER	HARDWARE	Qty
1	Frame	X 1
2	Standard Wheel	X 2
3	Swivel Wheel	X 2
4	Rail	X 1
5	Carriage Bolt	X 16
6	Nut	X 16
7	Washer	X 16
8	1/4" Phillips Bolt	X 4
9	1/4" Washer	X 4
10	1/4" Nut	X 4
11	Nylon Spacer	X 4
12	Extension Arm	x 4

