

# Model: BD1326

## Installation Instructions

### ASSEMBLY:

- Step 1.** Attach the crossbar's to the A-Frame's using the single brackets
- Step 2.** Attach the 5' Frame tube's without holes to the A-Frame's using single brackets.
- Step 3.** Attach the Bottom 5' Frame Tube with holes to the A-Frame using the single brackets.
- Step 4.** Slide in the Vertical Rung Bars to the Bottom 5' Frame Tube with holes.
- Step 5.** Slide the top 5' Frame Tube with holes onto the Vertical rung bars and attach to A-Frame with double brackets.
- Step 6.** Repeat steps 1-5 to add on another 5' section using the double brackets.
- Step 7.** Tighten down all nuts & bolts.

PART NUMBER	HARDWARE	Qty
1	2 pc. Single Bracket	18 pcs.
2	2 pc. Double Bracket	12 pcs.
3	A-Frame	5 pcs.
4	5' Frame Tube	8 pcs.
5	5' Frame Tube with holes	8 pcs.
6	Vertical Rung Bar	60 pcs.
7	2 1/2" x 3/8" / Carriage Bolt	72 pcs.
8	3/8" Nut	72 pcs.
9	Cross Bar	5 pcs.
10	Tube Cap	10 pcs.

**Double Bracket**



**Single Bracket**

