

# Model: BD1328

## Installation Instructions

### ASSEMBLY:

- Step 1.** Attach the crossbar's to the A-Frame's using the single brackets
- Step 2.** Attach the 5' Frame tube's without holes to the A-Frame's using single brackets.
- Step 3.** Attach the Bottom 5' Frame Tube with holes to the A-Frame using the single brackets.
- Step 4.** Slide in the Vertical Rung Bars to the Bottom 5' Frame Tube with holes.
- Step 5.** Slide the top 5' Frame Tube with holes onto the Vertical rung bars and attach to A-Frame with single brackets.
- Step 6.** Tighten down all nuts & bolts.

PART NUMBER	HARDWARE	Qty
1	2 pc. Single Bracket	12 pcs.
2	A-Frame	2 pcs.
3	5' Frame Tube	2 pcs.
4	5' Frame Tube with holes	2 pcs.
5	Vertical Rung Bar	15 pcs.
6	2 1/2" x 3/8" / Carriage Bolt	24 pcs.
7	3/8" Nut	24 pcs.
8	Cross Bar	2 pcs.
9	Tube Cap	4 pcs.

Single Bracket

