

LETTER PACKAGE COUNTS

CHARACTER	1/2" - KIT500	3/4" - KIT750	1" - KIT100	1-1/2" - KIT150
A	8	8	8	4
B	3	3	3	2
C	3	3	3	2
D	3	3	3	2
E	10	8	8	4
F	3	3	3	2
G	3	3	3	2
H	3	3	3	2
I	5	5	5	2
J	2	2	2	1
K	2	2	2	1
L	4	4	4	2
M	3	3	3	1
N	6	6	6	3
O	4	4	4	2
P	5	3	3	2
Q	1	1	2	1
R	6	6	6	3
S	6	6	6	2
T	6	6	6	2
U	6	3	4	1
V	1	1	2	1
W	1	2	2	1
X	1	2	2	1
Y	1	2	2	1
Z	1	2	2	1
*	6	6	6	1
slash	1	1	1	2
arrow	1	2	2	2
&	3	3	3	3
\$	3	2	2	2
.	10	10	10	4
“	4	4	4	n/a
cent sign	5	5	5	4
1	5	5	5	10
2	3	3	3	5
3	3	3	3	5

CHARACTER	1/2" - KIT500	3/4" - KIT750	1" - KIT100	1-1/2" - KIT150
4	3	3	3	5
5	8	8	8	13
6	3	3	3	6
7	3	3	3	5
8	3	3	3	5
9	3	3	3	5
0	3	3	3	6
pointer	1	1	1	1
euro sign	2	2	1	4
-	4	4	4	2
TOTAL	174	171	173	138