

Uniframe® Rectangular Tables

Inspection and Maintenance

Monthly Inspection/Maintenance Suggestions:

Inspect hardware to ensure proper seating - even with surface

- Inspect screws and enclosures that hold tops, benches, seats to the frame. Tap or screw hardware into place.

Inspect latch for proper alignment, locking

- Use latch set screw for adjustment.

Inspect cylinders attached to the tables are under pressure

- Cylinders that can be moved/wiggled with your hand while attached must be replaced. Contact your KI Customer Service personnel.

Every Three Months - Clean Casters

- Outside surface area of wheel - Use a putty knife to scrape clean any food, gum, dirt, etc.
- Axle bolt of wheel - Use putty knife to remove built-up dirt.

Semi-Annually

- Lubricate center pivot points on table.
(Only use spray lithium grease)

Annually

- Lubricate leg pivots located underneath the table.
(Only use spray lithium grease)

