Model: CL178 Installation Instructions



Below includes a brief illustration and description of how to set you Universal Latch Cable Locks to your desired combination



Step 1: Remove cable from lock. Located on one side of the locking mechanism you will see a small silver button. Press silver button to reset combination, keep the button firmly pressed down.



Step 2: While holding silver button down, turn dials to set your lock to the desired combination.



Step 3: Once combination is set attach cable to lock and press down on locking mechanism release button. Your lock has now been reset to desired combination.

Note: All cable locks are pre-set to 0-0-0. We suggest setting all cable locks to the same combination so that they are easy to remember. There is no way to unlock a cable lock without having the combination that has been set.

Phone: 800-930-6299 Fax: 800-964-4629 Email: help@SchoolFix.com