

SURFACE MOUNTED HINGES

TS409 & TS410 Installation Instructions

1. Set hinge leafs to pilaster per drawing.
2. Set UPPER hinge leaf to door. Adjust male cam as necessary to achieve desired closed position.
3. With door in "at rest" position set lower hinge leaf on door allowing 1/2" vertical space between hinge leafs as seen on drawing. (This allows for the rise of the door when opening).
4. Install black hinge pin. Install retaining clip into pin to prevent from coming out.
5. The hinges are handed for left hand (LH) or right hand (RH) swing. The same hinge (Part No. 409) may be used for LH inswing or RH outswing. The opposite hinge (Part No. 410) would be used for RH inswing or LH outswing.
6. To reverse the handing of the hinge, remove the inserts from the top hinge and insert them into the bottom hinge. Remove the plastic inserts from the bottom hinge and insert them into the top hinge. This will change the direction of the swing.
7. To adjust the position of the swing, drive pintle from bottom leaf of top door and turn to desired position.

