Uniframe® Round Tables Inspection and Maintenance

Monthly Inspection/Maintenance Suggestions:

Inspect hardware to ensure proper seating - even with surface

•Inspect screws and enclosures that hold tops, benches, seats to the frame. Tap or screw hardware into place.

Inspect latch for proper alignment, locking

Use latch set screw for adjustment.

Inspect cylinders attached to the tables are under pressure

 Cylinders that can be moved/wiggled with your hand while attached must be replaced. Contact your KI Customer Service personnel.

Every Three Months - Clean Casters

- Outside surface area of wheel Use a putty knife to scrape clean any food, gum, dirt, etc.
- •Axle bolt of wheel Use putty knife to remove built-up dirt.

Semi-Annually

Lubricate center pivot points of table frame.
(Only use spray lithium grease)

Annually

Lubricate leg pivots located underneath the table.
(Only use spray lithium grease)

